

# ColorBurst RIP Ver. 7.0


## Settings for using the Keyspan Adaptor (28X) with the DTP 41 on Mac OS 9.22

---



### Step 1: Install Keyspan Software

You will need to be using Version 1.9. If you do not have version 1.9 you can retrieve it from [www.keyspan.com/products/usb/usa28x/downloads/](http://www.keyspan.com/products/usb/usa28x/downloads/)



### Step 2: Open Keyspan USA28X Serial Assistant in the Control Panel

Check to make sure that you have Driver Version 1.9 then click on the advanced settings.

### Step 3: Make sure you have the following settings

**USE INTERRUPT ENDPOINTS:** Should be turned ON

**RECEIVE FIFO:** Should be set at 16

**DEFAULT BUFFER:** Should be set to 64

**DOUBLE BAUD RATE:** Should be active

Hit reset and close after making changes. Then unplug the adaptor and re-connect it and you are ready to go.

